



IP68 LED Underwater Light Installation Instructions


Installation Steps




1
Dig a suitable hole in the pool according to the size of the back box.



2
Place in the back box and fill with the appropriate filling so that it is flush with the top of the hole.



3
Pull the wire out of the back box and connect it with the wire on the lamp. It needs to correspond to each other and connect correctly.




4
Put the lamp into the back box and lock the screws.

Note:

1. Use the correct input voltage;
2. Cut off the power supply before installation and maintenance;
3. Do not disassemble the lamps at will, otherwise the lamps will not be waterproof;
4. The waterproof level of the cable interface must reach IP68;
5. The water must be free to run inside and outside of the back box, and cannot leak to the other side;
6. It must be installed underwater to prevent the lamp from being burnt due to overheating. The lamp cannot be on for more than 15 minutes without water.

IP68 LED Underwater Light Installation Instructions

Connection



Waterproof treatment (don't put joint part in water)



*** It is recommended to use IP68 waterproof connector for the cable interface, please make sure that the thread is tightened to prevent water from entering the connector due to misoperation.

Caution:

1. Only professional people to make installation, pls check the fixture well before installation.
2. Pls install the lights according to this datasheet carefully, screw the light well and connect the wire correctly.

Warning:

- *Neglect on action of the above treatment will lead to failure of waterproof and proper working of the lights!!
- *Make sure the ground connection well avoid electric shock, due to metal housing.

Note: The above instruction are subject to update or improved without notice. Pls turn to our staff for further details ! Thanks for your long term support !